

MN / MA VACUUM SWITCHES









VACUUM SWITCHES MN / MA

GENERAL INFORMATION:

MN / MA series vacuum switches are housed in pressure die cast aluminium powder coated enclosure and are recommended for panel mounting or outdoor service based on the type of enclosure opted for. The repeat accuracy is better than ± 2% FSR. A 3/8" cable entry is provided for cables and a terminal strip suitable for wired ends is provided inside the enclosure. Pressure port is 1/4" BSPF standard.

FEATURES:

Compact

Separate chamber for working parts Wide band adjustable differential in MA series.

Choice of wetted parts to suit working media

Electrical rating: 5A, 250VAC; 0.2A, 250 VDC

Pressure port: 1/4" BSPF

Some Applications: Used in grinding machines for holding jobs, vacuum systems, blowers, pumps, etc.

RANGE SELECTION TABLE MN MA Range vacuum (falling) *Adjustable Differential **Maximum Working** Range code *Approximate Maximum mm Hg ("Hg) Differential (Fixed) mm Hg (" Hg) Pressure bar (psi) mm Hg ("Hg) V00 760 - 100 100 100 - 500 12 (29.92 - 3.94)(3.94 - 19.69)(174.05)(3.94)

HOW TO ORDER MN / MA SERIES VACUUM SWITCHES

Group 1	Group 2	Group 3	Group 4	Group 5	Group 6
Model	Range Code	Range Scale	Disc	Diaphragm	Enclosure
MN - Fixed differential Vacuum Switch MA - Adjustable diff. Vacuum Switch	V00 - High range vacuum Switch	C - Calibrated U - Uncalibrated	A - Aluminium B - Brass S - SS 316	0 -Neoprene 1 -Teflon	0 -Standard (IP54) 1 -IP65 as per IS 2147

Eg. A fixed differential vacuum switch, high range from 760 mm Hg vac. To 100 mm Hg vac. in uncalibrated style, with brass pressure housing, a Teflon diaphragm & a standard enclosure shall be specified by

Group 1	Group 2	Group 3	Group 4	Group 5	Group 6
MN	V00	C	В	1	0

Please specify full model number to avoid ambiguty. If only the first two groups are specified while ordering, uncalibrated switches with standard wetted parts and enclosures will be supplied.

Continuous efforts for product development may necessitate changes in these details without notice





(Instruments Pot.)

B-501/504, 5th floor, Raunak Arcade, Near THC Hospital, Gokhale Road, Naupada, Thane(W) 400602. Maharashtra INDIA Telefax Nos.: 91-22-25301330 / 31 / 32 Web: http://www.nkinstruments.com E-Mail: sales@nkinstruments.com Skype: nitinkelkarskype

Gtalk: nkinstruments2006



^{*} Minimum differential increases with setpoint (Graphs available on request)

[†] Typical values achieved at sea level, total vacuum that can be achieved varies mainly with altitude.